### READ BEFORE OPERATING YOUR **POWEROLL™ CIGARETTE MACHINE**

Thank You and Congratulations on Your Purchase of the Premium PoweRoll™ Electric Cigarette Machine

Top-O-Matic® presents its newest addition to its line, the new PoweRoll™ Electric King Size Cigarette Machine. Its one-touch operation makes it extremely easy to use. The chamber guard is an added safety feature and tools are included for cleaning to keep your PoweRoll running smoothlu.

Please carefully read the instructions first before operating your machine! Following the simple

maintenance requirements will keep your machine in optimum working order for years to come.

We strongly recommend that you take the time to fill out and mail in your Warranty Card. Product must be registered for warrantu and service agreement to be valid within 30 days of purchase.

### **GETTING TO KNOW YOUR NEW POWEROLL CIGARETTE MACHINE**



PLEASE NOTE: The PoweRoll™Cigarette Machine makes KING SIZE cigarettes only.

power switch on. (Fig. A)



2 Slide the open end of a cigarette tube onto nozzle. (Fig. B)



(Fig. C)

4 Filling the corners first, deposit tobacco evenly in the Tobacco Chamber. DO NOT OVERFILL! (Fig. D)




**5.** Use Tamper to pack tobacco down evenly. (Fig. E)



7. Press AND release Chamber Guard over start button (as indicated) to activate injector. (Fig. G)

(Fig. F)





(Fig.E)

(Fig. G)



CAUTION

In the event of a jam, the machine will reset itself to the starting position and the Jam Indicator Light will flash. (Fig. H)

To clear the jam follow these steps:



## **OPERATING INSTRUCTIONS**

1 Plug in machine and turn the



(Fig. B)

 Open Chamber Guard (Fig. C)



(Fig. D)

(Fig. H)

### **OPERATING INSTRUCTIONS (CONT.)**

Clearing a Jam

1 After removing tube from nozzle, open Chamber Guard, then turn the Power Switch off. (Fig. I)



(Fig. I)

2 Use the supplied Clearing Rod and Nozzle Brush to remove all tobacco from Tobacco Chamber (Fig. J)



(Fig. J)

3 Turn the Power Switch on and close the Chamber Guard. (Fig. K)







# READ BEFORE OPERATING YOUR POWEROLL™ CIGARETTE MACHINE

### MAINTENANCE, CARE & HANDLING

- Keep cigarette machine out of the reach of children.
- Do not take machine apart!

  Doing so will void the warranty.
- Clean tobacco chamber and nozzle after every use.

· Clean your machine regularly by removing

Do not immerse machine in water.

the following types of tobacco:

- Overly dry tobacco

- Very fine cut tobacco

· To prevent jamming of the device, avoid

- Overly moist tobacco (such as pipe tobacco)

tobacco residue from tobacco chamber with

the supplied Clearing Rod and Nozzle Brush.



The use of other adaptors will void the warranty.



Do not overfill the tobacco chamber!

Doing so will cause the machine to jam.

Forcing the machine to inject jammed tobacco will void the warranty.



Always keep hands/fingers away from nozzle opening & tobacco chamber when

pressing the 'start' button to avoid cuts & lacerations. Extended injector is very sharp! (Fig. 1)



(Fig. 1)

### ADDITIONAL WARRANTY INFORMATION

### ADDITIONAL WARRANTY LIMITATIONS

The included one year, one time limited warrantly is your exclusive warrantly and it replaces all other warrantles or conditions, one present or implicet, including to the limited by the implicit warrantless or conditions and included the implicit warrantless or conditions. One present or implicit warrantless are particular proposed these warrantless of our allow the exclusion or limitation of expressed or implicit warrantless, so the above exclusion or limitation may not apply to you, in that event, such warrantles are limited in duration to the warrantle period. No warrantles are

### REMEDY LIMITATIONS

In no event shall the company be liable for special, incidental, or consequential demages to the purchaser or to any third party, including, without limitation, damages arising from loss of property, economic loss, lost profits, loss of business opportunity, or statisticy or exemplary damages, whether from negligence, warranty, strict labelity or under any legal theory in contract, lord, or otherwise. Some states do not allow the exclusion of mittation of special, incidental; or consequential damages, so the above limitation may not exply to you.

### RETURN PROCEDURE

Any product returned under those year, one time limited warranty should be sent by the customer via prepaid mail or courier to the service center located at 2301 Ravine Way, Glernéew, IL 60025, U.S.A. Please include with the returned product hevelve dollars and fifty corts ICS \$17.52 per to return a limit product in the store was assumed to responsible for any sub-ductives of the returned product in the store where you bought it for exprised before you benefit for service as they are not during during shipping and the outstorn is soldy responsible for any sub-durined sold service the product.

E SEE THE FUCLOSED ONE YEAR ONE TIME LIMITED WARRANTY CARD FOR MORE INFORMATION ON YOUR POWEROLL CIGARETTE MACHINE WARRANTY



### **OWNER'S MANUAL**



# KING SIZE ELECTRIC CIGARETTE MACHINE

©2013 Republic Tobacco L.P

See back panel for additional maintenance, care and handling tips.

Australian Reg. Des. No. 341218, Austrian Reg. Des. No. 64089, Benelux Reg. Des. No. 39134-00, Canadian 144262@ REPUBLICTOBACCO L.P., Chinese Reg. Des. No. 21201230037199.7, Chinese Utility Model No. 21201220403214, French Reg. Des. No. 20121949, German Reg. Des. No. 402012003315.4, Polish Reg. Des. No. Rp18676, Spanish Reg. Des. No. 054524, Turhish Reg. Des. No. 201200957, L. K. Reg. Des. No. 4023 409, U. S. Des. Pat. No. 659,901, other design and utility applications pending.



(Fig. L)