

Maintenance, Care & Handling

- **W** Keep the machine out of reach of children.
- Clean tobacco chamber & nozzle after use.
- Clean your machine regularly by blowing tobacco residue from moving parts. Use a cotton swab & warm water to clean the injector, tamper & tobacco chamber.
- The slip-resistant mat can be removed for cleaning.
- Keep all parts dust-free & lubricated with a multi-purpose household oil.
- To prevent jamming the machine, avoid the following types of tobacco:
 - Overly Moist Tobacco (such as pipe tobacco)
 - Overly Dry Tobacco Fine Cut Tobacco

- Avoid cuts and lacerations by keeping fingers clear of the crank arm's path! (See Fig. E)
- Avoid cuts and lacerations by keeping fingers clear of the tobacco chamber while operating the crank arm! (See Fig. F)
- NEVER rotate crank arm without a cigarette tube on nozzle! Extended injector is sharp!
- Do not overfill the tobacco chamber! Doing so will cause resistance in the crank arm and forcing the crank arm will void the warranty!











ADDITIONAL WARRANTY INFORMATION

ADDITIONAL WARRANTY LIMITATIONS

The included one time, one year limited warranty is your exclusive warranty and it replaces all other warranties or conditions, expressed or implied, including, but not limited to, the implied warranties or conditions of merchantability and fitness for a particular purpose. These warranties give you specific legal rights and you may also have other rights which vary from jurisdiction to jurisdiction. Some jurisdictions do not allow the exclusion or limitation or Everseed or implied warranties, so the above exclusion or limitation may not apply to you. In that event, such warranties are limited induration to the warranty period. No warranties apply after that period.

REMEDY LIMITATIONS

In no event shall the company be liable for special, incidental, or consequential damages to the purchaser or to any third party, including, without limitation, damages arising from loss of property, economic loss, lost profits, loss of business opportunity, or statutory or exemplary damages, whether from negligence, warranty, strict liability or under any legal theory in contract, tort, or otherwise. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

RETURN PROCEDURE

Any product returned under this one time, one year limited warranty should be sent by the customer via prepaid mail or courier to the service center located at 2301 Ravine Way, Glenview, IL 60025, U.S.A. Please include with the returned product twelve dollars and fifty cents (US \$12.50) for return shipping and handling. The company assumes no responsibility whatsoever for any loss or damage during shipping and the customer is solely responsible for any such loss or damage. Note: Please do not return the product to the store where you bought it for service as they are not authorized to service the product.

Owner's Manual

©Republic Tobacco L.P.

Austrian Patent No. 14351, Australian Patent No. 2013205376, Belgium Patent No. 102166481, Canadian Patent No. 2813447, Chinese Patent No. 2101201842845, Chinese Patent No. 21014035819.1, Spain Patent No. 2450715, United Kingdom Patent No. 2503327, Luxembourg Patent No. 29183, Netherlands Patent No. 2010682 United States Patent No. 9414625, United States Patent No. 20104812, Hungarian Patent No. 203626, Other patents pending

Read before operating your Supermatic® Cigarette Machine

Operating Instructions

Thank You & Congratulations on Your Purchase of the Premier® Supermatic® Cigarette Machine

Regarded as the finest tube injector in the world, the Premier® Supermatic® has rugged, all-metal construction & a unique tube size tab for both durability and versatility.

Please read the instructions carefully before operating your machine!

Slip Resistant Mat

Tobacco Chamber

Getting To Know Your Supermatic® Machine

Following the simple maintenance requirements will keep your machine in optimal working order for years to come.

Your Supermatic® must be registered within 30 days of purchase for warranty and service agreement to be valid.

Crank Arm

1) Return crank arm to start position. (Fig. A) Slide the open end of cigarette tube fully onto tube nozzle.(Fig. B)



(Fig. B)

2} Starting with the corners, fill the tobacco chamber evenly with loose tobacco. (Fig. C)



To get a better idea of how much tobacco to pack in the chamber, cut open a commercially made cigarette.



(Fig. C)

3} Rotate the crank arm clockwise in a smooth motion, then counterclockwise back to its home position. Remove your filled cigarette.



Making 100MM cigarettes

Supermatic[®] comes factory-ready to produce KING SIZE cigarettes. Lift & remove the Tube Sizing Tab to make 100MM cigarettes.







Tube Clamp